

Primrose Window Film Instructions

Required tools

A cutter, a ruler, a squeegee, a scraper, paper towel, card, Stanley knife and a spray bottle containing a solution of 1 litre of water and 50ml of dishwashing detergent.

Attention

- Apply the film to smooth glass.
- Avoid creasing and folding the film (handle with care)
- Avoid dust free situations
- Adhesive films can be applied internally on all types of flat glass. The adhesive side is protected by a layer (liner) which is lifted just before fitting the film.

Preparation

1. Clean the glass area with the solution. Use a window scraper to remove any specks etc.

Note: When using the scraper make sure the glass is wet otherwise scratches may occur.

2. Squeegee dry.

3. Measure and mark the film with a ruler and pen, make sure its enough to cover the glass area. (Allow an extra 2-3 cm for the length and width)

Handling film

1. One side of the film is protected by a clear liner - adhesive side.

2. Once the film is measured and marked up, use a cutter to cut the film accurately your desired size, allow extra 2-3cm for the length and width. (Excess material can be trimmed after installation)

Applying the film

1. Wet the glass with the solution.

2. Place the film onto the glass area (clear side facing you) Now carefully peel off the liner. Freely spray the solution on the adhesive surface.

3. Reverse the film onto the glass so that the adhesive side is now in contact with the glass. The edge should be against the glass frame.

Note: Try and avoid the film from curling up on itself. Keep the film straight and avoid creasing.

4. Position the film by carefully sliding on the wet surface. Time to smooth out any air bubbles. Ensure the whole glass area is covered by the film.

Using the Squeegee

1. Wet the face of the film with the solution and use a squeegee to squeeze out all of the solution.

Note: Ideal to start at the top horizontally from the middle out.

2. Now use the squeegee downwards down the middle of the film. Then squeegee across to the edges of the film.

Note: Important to make sure all of the solution is squeezed out from under the film. If there is a trapped particle behind the film, carefully lift the film from the nearest corner. Wet the adhesive side of the film again and place into position. Wet the face of the film and use the squeegee technique again.

Trimming

1. Use a credit card and Stanley knife down the edge of the glass frame. To avoid any slip ups, trap the blade of the knife between the card and the frame.

2. Discard the excess material

3. Repeat the squeegee technique again, this time with firm pressure. This is to create a strong bond.

Inspect/ final checks

1. If you spot any water remains, dry with some paper towel.

2. Inspect the film for any trapped water or air bubbles and squeeze out.

Note: During the drying time, some haze or mist or vapor will be evident but this will disappear and dry out in a period of 2-4 weeks.

Care

You should look after film in the same manner as glass. Use classic glass cleaning products and draw on the squeegee.

Do not clean dry. Do not use brushes, fabrics or abrasives.